

1. Break off the buckle that you would like to replace, keeping the webbing loop intact.
2. Hook both sides of the new female part of the buckle into the webbing loop.
3. Remove the male side of the buckle from the other end of the strap that is hanging inside the Softopper canopy.
4. Feed the webbing through the male end of the buckle as shown.

